

# 51.2V

# LiFePO4 Battery

LFP48100P~48230P



# USER MANUAL


# CONTENT

1. Safety Instructions .....	1
2. Product Overview .....	1
3. Battery Specifications .....	2
4. List of Accessories .....	3
5. Connection .....	3
5.1. Battery module .....	3
5.2. Communication cable .....	3
6. Working Mode .....	4
6.1. Basic Mode .....	4
6.2. Description of Reset Button .....	4
7. LED Indicator Description .....	4
7.1. LED Indicator Description .....	4
7.2. SOC Capacity Indicator .....	5
7.3. Status Indicator .....	5
7.4. Flash Instruction of LED Indicators .....	6
8. LCD Display Introduction .....	6
8.1. Power-on screen .....	6
8.2. Main menu .....	6
8.3. Sub-menu 1: BMS Parameter .....	7
8.4. Sub-menu 2: Battery Status .....	7
8.5. Sub-menu 3: GYRO Status .....	8
8.6. Sub-menu 4: Version Number .....	8
8.7. Dormancy and Activation Function .....	8
9. Communication .....	8
9.1. Pin Definition of Communication Interface .....	8
9.2. DIP Switch Setting .....	9
9.3. Settings for no communication situation .....	10
10. Upper Computer Software Introduction .....	10
10.1. How To Communicate With Upper Computer .....	10
10.2. Upper Computer Software Introduction .....	10
11. Warranty Policy .....	16
12. Appendix I .....	18

## 1. Safety Instructions

1. Please confirm the package is in good condition after getting the product. If there is any damage, please take photos to record and contact the supplier in time.
2. Because this is an electronic energy storage product, please handle it gently, and please pay attention to safety when moving products.
3. After unpacking, please check whether the product appearance is intact, press the ON/OFF switch to start the battery, confirm whether it can be turned on normally, and whether the LCD screen is displayed normally.
4. Please connect to other devices in the correct way with the battery power off.
5. After devices connected, before turning on the battery, please turn off the loads (including the inverter). If it is turned on with loads, it may trigger the BMS short-circuit protection mechanism.
6. Charge as required, take 51.2V products as an example: normal charging voltage is 57.6V-58.4V, recommend current 0.2C. Mismatched current and voltage will cause damage to the circuit system, shorten the service life of the battery, and even bring safety hazards.
7. Charge rate should not exceed 0.5C, discharge rate should not exceed 0.7C.
8. Avoid using it in humid environments and in areas where it will be exposed to sunlight.
9. When not in use for a long time, it should be charged regularly, and it is best to keep half-charged storage (40%-60%).
10. Battery should be recharged within 12 hours after being fully discharged.
11. When different batches of batteries are installed in the same system, all batteries should be balanced to the same voltage (the voltage difference within 0.3V) by charging and discharging individually.
12. Do not disassemble the equipment without professional assistance.
13. Do not connect batteries with different brands or different capacities.

## 2. Product Overview







No.	Item	Function
1	Positive Terminal	Charge & Discharge
2	SOC	Indicators for Capacity
3	ALM	Indicator for Alarms
4	RUN	Indicator for Running Status
5	ADD	DIP Switch of Communication
6	Negative Terminal	Charge & Discharge
7	Power Switch	ON/OFF Switch
8	Reset	Activate/Hibernate BMS
9	RS485A, RS485B/CAN	Communication Interface
10	LCD Screen	Display Battery Information

### 3. Battery Specifications

Nominal Parameters					
Model No.	LFP48100P	LFP48120P	LFP48150P	LFP48200P	LFP48230P
Nominal Voltage	51.2V	51.2V	51.2V	51.2V	51.2V
Nominal Capacity	100Ah	120Ah	150Ah	200Ah	230Ah
Energy	5.12KWh	6.14KWh	7.68KWh	10.24KWh	11.78KWh
Dimensions (L * W * H mm)	480*440*160	480*440*200	480*440*200	480*440*255	480*440*255
Weight (KG)	Approx 45	Approx 52	Approx 55	Approx 70	Approx 80
Built-in BMS	16S 100A	16S 100A	16S 200A	16S 200A	16S 200A
Electrical Parameters					
Overall Over Voltage Alarm Value	58.2VDC				
Overall Under Voltage Alarm Value	44VDC				
Overall Over Voltage Protection Value	58.4VDC ✓				
Overall Under Voltage Protection Value	42VDC				
Recommend Charge & Discharge Current	0.2~0.5C				
Max. Cont. Discharge Current	100A	100A	150A	200A	200A
Basic Parameters					
Life Time(25°C)	10+ years				
Communication Interface	RS485 / CAN				
Display Method and Language	LCD, English				
Life Cycles (80% DOD, 25°C)	≥6000 times Cycles				
Charge Temperature Range (Cell)	0°C~50°C				
Discharge Temperature Range (Cell)	-15°C~55°C				
Environmental Temperature Range	-15°C~55°C				

## 4. List of Accessories

No.	Item	Picture	Qty	Remarks
1	Parallel Power Cable		2	For 51.2V 100AH/120AH: 6 AWG cable 0.3M  For 51.2V 150AH/200AH/230AH: 4 AWG cable 0.4M
2	Parallel Communication Cable		1	RJ45 cable 0.5M
3	Upper computer Connecting Cable		1	RJ45 to USB cable 2M
4	Screws		4	M8

## 5. Connection

### 5.1. Battery module

If there are multiple batteries to be connected in parallel, ensure that the voltage difference of all batteries is within 0.3V before proceeding. If the voltage difference is over 0.3V, discharge all batteries until the low voltage alarm and discharge stops. Confirm the voltage difference is within 0.3V, then ensure all battery modules are turned off. Connecting each battery module "+" (positive) and "-" (negative) terminal to "+" (positive) and "-" (negative) busbar. Connect all sources and loads to the busbar, observing proper polarity. Note: There may be fuses, contactors, switches, etc. between the busbar and the connected sources and/or loads.

### 5.2. Communication cable

If a single battery is used, skip this step.

When multiple batteries are connected in parallel, set the battery module Address (or ID) of each battery module according to page 9~10 (also ensure no duplicate address codes are used). Then connect one end of the provided RJ45 communication cable into a battery module front panel "RS485A" or "RS485B" interface and connect the remaining end of the RJ45 communication cable into another battery module front panel "RS485A" or "RS485B" interface. Continue connecting communication cables until all battery modules are connected.

## 6. Working Mode

### 6.1. Basic Mode

#### 6.1.1. Charging Mode

The BMS turns on the charging MOSFET for charging when it detects an external charging voltage, and the cell voltage and temperature are within the chargeable range. When the charging current reaches the effective charging current, it enters the charging mode. Both charging and discharging MOSFETs are on in charge mode.

#### 6.1.2. Discharging Mode

The BMS enters the discharge mode when it detects that the load is connected and the cell voltage and temperature are within the dischargeable range and the discharge current reaches the effective discharge current.

#### 6.1.3. Hibernation and Wake Up Mode

The system enters hibernation mode when the following conditions are met:

1. Individual low-voltage protection or overall low-voltage protection has not been released within 60 minutes;
2. Press the power switch button for 3 seconds and then release the button;
3. The minimum cell voltage is lower than the dormancy set voltage (default value 3300mV), and the duration reaches the delay time (the default value is 1440min, which meets the requirements of no communication and no charging and discharging current at the same time);
4. Compulsory shutdown through the upper computer software.

Before entering hibernation, make sure that the negative terminal is not connected to external voltage, otherwise it will not be able to enter the low power consumption mode.

5. The wake-up conditions of hibernation mode:

- 1) Connect to the charger, and the input voltage of the charger must be greater than 48V;
- 2) Wake up by pressing the power switch button for 1S and releasing the button.

### 6.2. Description of Reset Button

When the BMS is dormant, press the button for 1S and then release it, the BMS will be activated and the LEDs will light on sequentially for 0.5 seconds starting from the "SOC4".


When the BMS is in the working state, press the button for 3S~6S and then release it, the BMS will enter dormant and the LEDs will go off sequentially for 0.5S starting from "RUN".

When the BMS is in the working state, press the button for  $\geq 6S$  and then release it, the BMS will be reset, and the LEDs will display according to the current electricity level.

## 7. LED Indicator Description

### 7.1. LED Indicator Description

Four green capacity indicators, one red alarm indicator, one green running indicator

SOC4 ●	SOC3 ●	SOC2 ●	SOC1 ●	●	●
SOC 				ALM	RUN

## 7.2. SOC Capacity Indicator

Status	Charge				Discharge			
SOC Indicator	SOC4 ●	SOC3 ●	SOC2 ●	SOC1 ●	SOC4 ●	SOC3 ●	SOC2 ●	SOC1 ●
0~25%	Flash 2	OFF	OFF	OFF	ON	OFF	OFF	OFF
25~50%	ON	Flash 2	OFF	OFF	ON	ON	OFF	OFF
50~75%	ON	ON	Flash 2	OFF	ON	ON	ON	OFF
75~100%	ON	ON	ON	Flash 2	ON	ON	ON	ON
RUN Indicator ●	ON				Flash 3			


## 7.3. Status Indicator

Status	Normal / Alarm / Protection / Fault	SOC				ALM	RUN	Remark	
		●	●	●	●	●	●		
OFF	OFF	ALL OFF						1. There are only normal and alarms in standby mode. Protection and faults are reported as charging and discharging status.	
Standby	Normal	ON according to battery capacity				OFF	Flash 1		
	Alarm					Flash 2	Flash 1		
Charge	Normal	ON according to battery capacity (The largest SOC LED Flash 2)				OFF	ON	2. Alarms include: over voltage difference alarm, low capacity alarm, over voltage and low voltage alarm of single cell or whole battery, temperature alarms.	
	Alarm					Flash 2	ON		
	Over Voltage Protection	ON according to battery capacity				OFF	ON		
	Over Current Protection (Enter current limit charging)	ON according to battery capacity (When there is charging current, the largest SOC LED Flash 2)				OFF	ON		
	Temperature Protection	ALL OFF				ON	OFF		
Discharge	Normal	ON according to battery capacity				OFF	Flash 3		3. When charging over current protection occur, it will enter current limited charging. If there is charging current, it will displayed as normal state; if no charging current, it will displayed as fault state, ALM ON and others OFF.
	Alarm					Flash 2	Flash 3		
	Low Voltage Protection					Flash 2	OFF		
	Over Current Protection, Short Circuit Protection	ALL OFF				ON	OFF		
	Temperature Protection	ALL OFF				ON	OFF		
Fault	NTC fault, MOS fault, reverse polarity, differential voltage protection, ultra-low voltage protection	ALL OFF				ON	OFF		

### 7.4. Flash Instruction of LED Indicators

Flash Types	ON	OFF
Flash 1	0.25 S	3.75 S
Flash 2	0.5 S	0.5 S
Flash 3	0.5 S	1.5 S

## 8. LCD Display Introduction



### Button description:

**MENU:** Enter the main menu.

**ENTER:** Enter to the sub-menu.

**UP:** Move to next page.

**ESC:** Return to the previous menu.

### 8.1. Power-on screen



System Date	SOH
Charging/Discharging Current	Environmental Temperature
Total Voltage	Max. Temperature of Battery Cell
Remaining Capacity	SOC
Max. Voltage of Single Cell	Min. Voltage of Single Cell

### Battery protection status:

Over Voltage: OV

Low Voltage: LV

Over Temp: OT


Low Temp: LT

Over Current: OC


Short Circuit: SC

**Note:** When there is protection situation of the battery, there will show the corresponding protection status, otherwise, the protection status will not be showed.


### 8.2. Main menu



### 8.3. Sub-menu 1: BMS Parameter




### 8.4. Sub-menu 2: Battery Status



### 8.5. Sub-menu 3: GYRO Status



### 8.6. Sub-menu 4: Version Number





### 8.7. Dormancy and Activation Function

After 1 minute of no button operation in normal running, the display screen will be off (only the backlight is off). Pressing any button while the screen is off will allow the screen light and operate normally.


## 9. Communication

With RS485 and CAN interface, which supports communicating with multiple battery modules in parallel, with inverter and with the upper computer. RS485 baud rate is 9600 defaulted, CAN baud rate is 500K defaulted.

### 9.1. Pin Definition of Communication Interface




8P8C RJ45 Pins Assignment		
Pins	Definition	Remark
1	RS485A_B	For communication with upper computer or inverter
2	RS485A_A	
3, 6	GND	
4, 5	NC	
7	RS485B_A	For communication between multiple battery modules
8	RS485B_B	



8P8C RJ45 Pins Assignment		
Pins	Definition	Remark
1	RS485A_B	For communication with upper computer or inverter
2	RS485A_A	
3, 6	GND	
4	CANH1	For communication with inverter
5	CANL1	
7	RS485B_A	For communication between multiple battery modules (only slave batteries)
8	RS485B_B	


The multi-unit parallel connections are shown in the following figure.



## 9.2. DIP Switch Setting

Support battery modules parallel and inverter communication protocol selection.

When batteries are used in parallel, different batteries are distinguished by the dial address (or "ID"), and the ID of each battery in the entire battery group is unique.



There will be only one master battery and others will be slave batteries. The slave dialing address should be selected from 1 to 15, and the master dialing address should be selected from 0 or 16 or 32 or 48 according to the different communication protocol and inverter brand.

You can enter the ID of master or slave battery in the system parameters in upper computer monitor software to detect and communicate.

**Note:** The factory default settings support up to 16 batteries in parallel, if more than 16 batteries are needed in parallel, please contact manufacturer to upgrade the software (supports up to 32 batteries in parallel).

The reference table is as follows.

### FOR SLAVE BATTERY

DIP SWITCH						ADD (ID)	REMARKS
1	2	3	4	5	6		
ON	OFF	OFF	OFF	OFF	OFF	1	Slave Pack 1
OFF	ON	OFF	OFF	OFF	OFF	2	Slave Pack 2
ON	ON	OFF	OFF	OFF	OFF	3	Slave Pack 3
OFF	OFF	ON	OFF	OFF	OFF	4	Slave Pack 4
ON	OFF	ON	OFF	OFF	OFF	5	Slave Pack 5
OFF	ON	ON	OFF	OFF	OFF	6	Slave Pack 6
ON	ON	ON	OFF	OFF	OFF	7	Slave Pack 7
OFF	OFF	OFF	ON	OFF	OFF	8	Slave Pack 8
ON	OFF	OFF	ON	OFF	OFF	9	Slave Pack 9
OFF	ON	OFF	ON	OFF	OFF	10	Slave Pack 10
ON	ON	OFF	ON	OFF	OFF	11	Slave Pack 11
OFF	OFF	ON	ON	OFF	OFF	12	Slave Pack 12
ON	OFF	ON	ON	OFF	OFF	13	Slave Pack 13
OFF	ON	ON	ON	OFF	OFF	14	Slave Pack 14
ON	ON	ON	ON	OFF	OFF	15	Slave Pack 15

**FOR MASTER BATTERY.**

DIP SWITCH						ADD (ID)	REMARKS
1	2	3	4	5	6		
Communicate via CAN Communication Protocol							
OFF	OFF	OFF	OFF	OFF	OFF	0	LXP
OFF	OFF	OFF	OFF	OFF	ON	32	Pylon, Deye, Goodwe, Solis
OFF	OFF	OFF	OFF	ON	OFF	16	Victron, SMA, Sofar
OFF	OFF	OFF	OFF	ON	ON	48	Growatt, Sacolor
Communicate via RS485 Communication Protocol							
OFF	OFF	OFF	OFF	OFF	OFF	0	SRNE
OFF	OFF	OFF	OFF	OFF	ON	32	Voltronic

**9.3. Settings for no communication situation**

Without communication protocol, inverter cannot communicate with our battery. You need to make some setting on your inverter, for example, select the user-defined mode and set the corresponding voltage level (according to the inverter user manual), so that they can work together without communication.

Here are some commonly used battery parameters that need to be set, for reference. If need more advices about battery parameters settings, please contact the manufacturer.

Over Voltage Disconnect Voltage	57.6V
Charging Limit Voltage	58.4V
Equalizing Charging Voltage	56V
Float Charging Voltage	54V
Low Voltage Warning Voltage	45V
Cut-off Discharge Voltage	43.2V
Discharge Limit Voltage	40V

**10. Upper Computer Software Introduction**


To monitor the battery module parameters, connect the RJ45 end of the provided upper computer communication cable into a battery module front panel "RS485A" or "RS485B" interface, and connect the USB end to computer.

**10.1. How To Communicate With Upper Computer**


See Appendix I on page 18~19.

**10.2. Upper Computer Software Introduction**


1. Enable the monitoring software, select the communication interface of the corresponding device, select the corresponding baud rate, and finally click "Open Serial Interface" to communicate with BMS and get the basic parameters. (picture on next page)



2. You can change the version in Chinese or English in help center.



3. After the BMS communicates with the upper computer, you can monitor the basic parameters and status of the battery in real time. These information include battery voltage, current, SOC, SOH, cycle count, battery temperature, alarm status, protection status, etc.



4. You can view the real-time data storage of the BMS and export as excel tables.

No	time	Total volt	Total curr	SOC(%)	SOH(%)	Full capacity	The remain	The num	Env TEMP(°C)	MOS TEMP(°C)	Alert status	PROT state	Cell Num
1	2023-05-25 17:19:04	53.29	0.00	100.00	100	107.23	107.23	1.0	28.0	28.0			16
2	2023-05-25 17:19:05	53.29	0.00	100.00	100	107.23	107.23	1.0	28.0	28.0			16
3	2023-05-25 17:19:06	53.29	0.00	100.00	100	107.23	107.23	1.0	28.0	28.0			16
4	2023-05-25 17:19:07	53.29	0.00	100.00	100	107.23	107.23	1.0	28.0	28.0			16
5	2023-05-25 17:19:08	53.29	0.00	100.00	100	107.23	107.23	1.0	28.0	28.0			16
6	2023-05-25 17:19:09	53.29	0.00	100.00	100	107.23	107.23	1.0	28.0	28.0			16
7	2023-05-25 17:19:10	53.29	0.00	100.00	100	107.23	107.23	1.0	28.0	28.0			16
8	2023-05-25 17:19:11	53.29	0.00	100.00	100	107.23	107.23	1.0	28.0	28.0			16
9	2023-05-25 17:19:13	53.29	0.00	100.00	100	107.23	107.23	1.0	28.0	28.0			16
10	2023-05-25 17:19:14	53.29	0.00	100.00	100	107.23	107.23	1.0	28.0	28.0			16
11	2023-05-25 17:19:15	53.29	0.00	100.00	100	107.23	107.23	1.0	28.0	28.0			16
12	2023-05-25 17:19:16	53.29	0.00	100.00	100	107.23	107.23	1.0	28.0	28.0			16
13	2023-05-25 17:19:17	53.29	0.00	100.00	100	107.23	107.23	1.0	28.0	28.0			16
14	2023-05-25 17:19:18	53.29	0.00	100.00	100	107.23	107.23	1.0	28.0	28.0			16
15	2023-05-25 17:19:19	53.29	0.00	100.00	100	107.23	107.23	1.0	28.0	28.0			16
16	2023-05-25 17:19:20	53.29	0.00	100.00	100	107.23	107.23	1.0	28.0	28.0			16

5. When monitoring multiple packs, you need to set the start and end address of packs manually, you can check and compare the data of each pack. And you can also export as excel table.

No	time	PACK	Total volt	Total curr	SOC(%)	SOH(%)	Full capacity	The remain	The num	Env TEMP(°C)	MOS TEMP(°C)	Current state	Alert status	PROT state
1	2023-02-13 10:25:01	1	53.32	0.00	100.00	100	107.25	107.25	1.0	26.0	23.0	Charge, Charge		
2	2023-02-13 10:25:05	1	53.32	0.00	100.00	100	107.25	107.25	1.0	26.0	23.0	Charge, Charge		
3	2023-02-13 10:25:06	1	53.32	0.00	100.00	100	107.25	107.25	1.0	25.6	23.0	Charge, Charge		
4	2023-02-13 10:25:07	1	53.32	0.00	100.00	100	107.25	107.25	1.0	26.0	23.0	Charge, Charge		
5	2023-02-13 11:16:32	1	53.31	0.00	100.00	100	107.25	107.25	1.0	26.0	24.0	Charge, Charge		
6	2023-02-13 11:16:36	1	53.31	0.00	100.00	100	107.25	107.45	1.0	26.0	23.0	Charge, Charge		
7	2023-02-13 11:16:37	1	53.31	0.00	100.00	100	107.25	107.45	1.0	26.0	24.0	Charge, Charge		
8	2023-02-13 11:16:38	1	53.31	0.00	100.00	100	107.25	107.25	1.0	26.0	24.0	Charge, Charge		
9	2023-05-25 17:20:27	1	53.29	0.00	100.00	100	107.23	107.23	1.0	28.0	27.0	Charge, Charge		

6. Parameters 1.

Click "Get All" when enter for the first time.


This section includes reading basic parameter information, restoring default parameters, writing individual parameters, writing all parameters, importing parameters and exporting parameters (it is not recommended to manually modified default parameters). (picture on next page)



7. System parameter setting.

Click "Get" when enter for the first time.


You can monitor the BMS parameters configuration, sleep settings and BMS information in real-time(it is not recommended to manually modified default parameters).




8. Calibration: Here is calibration content of BMS data (all has calibrated by factory, not recommended for private calibration). (picture on next page)



9. Wireless module: Here will contains information about some additional functional modules.



10. Basic control: Here includes the control of charging and discharging MOS, heating and other states (please consult the manufacturer for operation).



11. Upgrade: software online upgrade function of BMS (please consult the manufacturer for operation).



12. Click "Read Data" to get historical data and export data.

The screenshot shows the BMS software interface displaying a table of historical data. The 'Read Data' and 'Export' buttons are highlighted with red boxes. The table has the following columns: No, PACK, Time, Event Record, Total volt., Total curr., SOCC(%), SOH(%), Full capacity, Env TEMPL., MOS TEMP., Cell N., V difference, battery01, battery02, battery03. The data rows show various system events and battery parameters over time.

No	PACK	Time	Event Record	Total volt.	Total curr.	SOCC(%)	SOH(%)	Full capacity	Env TEMPL.	MOS TEMP.	Cell N.	V difference	battery01	battery02	battery03
1	1	2023-03-29 14:42:08	System run	53.30	0.00	100.00	100.00	107	27.00	27.00	16	3	3.333	3.334	3.335
2	1	2023-03-29 17:19:49	Enter sleep	53.30	0.00	100.00	100.00	107	25.00	25.00	16	2	3.334	3.334	3.335
3	1	2023-03-29 16:24:15	System run	53.30	0.00	100.00	100.00	107	25.00	25.00	16	2	3.335	3.336	3.336
4	1	2023-03-20 19:44:06	Enter sleep	53.30	0.00	100.00	100.00	107	27.00	27.00	16	2	3.328	3.328	3.329
5	1	2023-03-19 17:43:35	Time exceeding	53.30	0.00	100.00	100.00	107	26.00	26.00	16	2	3.329	3.329	3.329
6	1	2023-03-18 17:03:36	Time exceeding	53.30	0.00	100.00	100.00	107	26.00	26.00	16	3	3.329	3.329	3.329
7	1	2023-03-17 17:02:30	System run	53.30	0.00	100.00	100.00	107	25.00	25.00	16	2	3.333	3.333	3.334
8	1	2023-03-14 15:35:54	Enter sleep	53.30	0.00	100.00	100.00	107	27.00	27.00	16	1	3.330	3.330	3.331
9	1	2023-03-13 15:46:07	System run	53.30	0.00	100.00	100.00	107	28.00	28.00	16	2	3.333	3.333	3.333
10	1	2023-03-13 15:49:04	Enter sleep	53.30	0.00	100.00	100.00	107	27.00	27.00	16	1	3.331	3.331	3.331
11	1	2023-03-13 15:49:33	System run	53.30	0.00	100.00	100.00	107	25.00	25.00	16	1	3.333	3.333	3.334
12	1	2023-03-13 15:49:29	Enter sleep	53.30	0.00	100.00	100.00	107	25.00	25.00	16	2	3.333	3.332	3.333
13	1	2023-03-13 15:43:39	System run	53.30	0.00	100.00	100.00	107	25.00	25.00	16	2	3.333	3.333	3.334
14	1	2023-03-10 10:16:17	Enter sleep	53.30	0.00	100.00	100.00	107	27.00	27.00	16	2	3.330	3.330	3.330
15	1	2023-03-10 10:59:51	System run	53.30	0.00	100.00	100.00	107	25.00	25.00	16	2	3.333	3.333	3.334
16	1	2023-03-09 10:06:09	Enter sleep	53.30	0.00	100.00	100.00	107	23.00	23.00	16	2	3.332	3.332	3.333

## 11. Warranty Policy

Offers standard factory warranty which is valid for 5 years for battery products, from the date of installation or no more than 5 and a half years from the delivery date from the factory.

### 1. Product Quality Standards and Warranty

- 1) Battery complies with safety transportation related to UN38.3 and MSDS.
- 2) The battery warranty is decided by manufacturer and its distributor.
- 3) After the products left factory, the appearance damage (scratches, rust, chemical damage) is beyond warranty.

### 2. Warranty Exceptions

- 1) Damage or lose to battery or accessory caused by logistics.
- 2) Battery failure caused by non- compliance inverters or chargers which lead to e. g. abnormal charge voltage, unqualified inverter or charger.
- 3) Battery malfunction or damage caused by non-professional or non-qualified personnel.
- 4) Failure to observe the user manual, the installation guide, and the maintenance regulations.
- 5) Product malfunction or damage due to disobey to relevant laws and regulations or technical requirements in power plant design, construction, or installation works.
- 6) Connect high voltage inverter to low voltage battery or connect low voltage inverter to high voltage battery.
- 7) Product malfunction or damage due to installation on movable device or in vibration occasions.
- 8) Failure or damage caused by corrosion, lightning and other natural damage or force majeure.
- 9) Unauthorized alteration or disassembly of the product.
- 10) Damage or malfunction caused by other facilities e.g. Surge damage caused by switching on/off high power generator.

### 3. Repair and Replacement

When a failure occurs, the user should check and record from the screen display the error code, protection values and necessary information.

When the dealer or manufacturer confirmed that is a product quality problem, the faulty product will be repaired and replaced by spares.

Manufacturer is only responsible for the company's products troubleshooting, repair and replacement, but doesn't assume any other special damages, consequential damages, or incidental damages ( including loss of profits, loss of goodwill, loss of business reputation loss or delay, etc.).

This warranty does not affect the customer's enjoyment of any other rights laws and regulations relating to sales of consumer goods provided for in the host country or region.

Customers could contact local dealers or distributors to discuss how to proceed.

### 4. Force Majeure

Force majeure is not artificially unavoidable and insurmountable objective condition. In addition, it is the loss that even if the use of methods of prevention and attention, cannot prevent. It includes the following:

- 1) Earthquakes, floods, fires, storms and other natural disasters.
- 2) War, invasion, blockade and other hostile armed actors.
- 3) Revolution, rebellions, riots.
- 4) Strike.
- 5) Collection, prohibition, and other provisions of the government's actions.
- 6) Infectious diseases.
- 7) Third-party negligence and wrongdoing that manufacturers cannot control.

**5. Warranty Disclaimer**

We make no representations or warranties regarding the Product other than those expressly stated in this Limited Warranty. The foregoing Limited Warranties are exclusive and in lieu of all other express and implied warranties whatsoever. We specifically disclaim any implied warranties of merchant ability or fitness for a particular purpose. To the fullest extent that damages may be disclaimed by law, We shall not be liable, whether in contract or tort (including negligence and strict liability), for any damages in excess of the Product's purchase price or for any indirect, incidental, special, or consequential damages of any kind, or any loss of revenue, profits, business, information, data, or any other financial loss arising out of or in connection with the use or inability to use the Product.

**6. Legal Rights**

Some countries and/or states do not allow limitations on how long an implied warranty lasts or the exclusion or limitation of incidental or consequential damages, so the above limitations may not apply to you. This warranty gives you specific legal rights, which may vary from country to country and/or state to state. This warranty shall be governed by and interpreted in accordance with the laws of China. This warranty is understood to be the exclusive agreement between the parties relating to the subject matter hereof. No employee or representative of us is authorized to make any warranty in addition to those made in this agreement.


**7. Product Sustainability Guarantee**

As a lifepo4 battery pack manufacturer, we committed to achieving the vision of sustainability through investment in products and efforts, we minimize waste, improve the performance of products and processes in terms of environment, health and safety, and use fewer resources. to provide competitive products and technologies in order to meet the needs of the market Demand. We also analyze the impact of the product life cycle and continue to develop innovative products that are durable, contain recycled or renewable ingredients, can be recycled, or help improve the environmental performance of final products. We work with suppliers and partners to promote responsible environmental management and the common goal of improving sustainability. We are committed to maintaining a safe and healthy workplace and creating more value in this area that is focused on renewable energy and sustainability.


## 12. Appendix I

### How To Communicate With Upper Computer (PC/laptop)


1. Turn on the battery by pressing the power switch, set the dip "1" as "ON" on the battery.



2. Connect the battery ("RS485A" or "RS485B" interfaces both work) with computer by RJ45 to USB cable.



3. Download and install the driver on your computer.




4. Download the folder "DR software", you will find a app "DrStartApp" in folder, double click and open it.



5. Some setting up on software. (picture on next page)

- 1) Click "Series ON",
- 2) "Addr": select as "1",
- 3) "Baud rate": select as "9600",
- 4) "Serial": select each COM one by one, until you can see data on the page changes in real time, it means that is the suitable COM serial.



6. Due to the real-time monitor function, when they communicate successfully, the data on page will change in real time.

The screenshot displays a BMS monitoring interface with the following components:

- Cell V Table:**

Cell ID	Voltage (V)	Status
Max diff	2	mV
Cell 01	3.334	
Cell 02	3.334	
Cell 03	3.325	High
Cell 04	3.334	
Cell 05	3.335	
Cell 06	3.334	
Cell 07	3.335	
Cell 08	3.334	
Cell 09	3.334	
Cell 10	3.335	
Cell 11	3.335	
Cell 12	3.334	
Cell 13	3.335	
Cell 14	3.335	
Cell 15	3.333	
Cell 16	3.334	
- Info of BMS:**
  - Voltage: 53.34 V
  - Current: 0.00 A
  - Cycles: 1 Times
  - ENV: 28.0 °C
  - MOS: 28.0 °C
  - Max diff: 1.0 °C
  - Cap Full: 107.23Ah
- Serial Settings:**
  - Serial: COM3
  - Baud rate: 19200
  - Interval: 1s
  - Addr: 1
  - Monitoring: Sent 273, Parsed 35
- System Status:**
  - Info of System: DISCH/MOS, Charge/MOS
  - Alarm Status: None
  - Protect Status: None
  - Fault Status: None
- Real-time data Table:**

No	time	Total volt...	Total curr...	SOC(%)	SOH(%)	Full capacity...	The remaini...	The num...	Env TEMP(°C)	MOS TEMP(°C)	Alert status	PROT state	Cell Num
1	2022-10-21 12:21:22	53.38	0.00	100.00	100	107.23	107.23	1.0	27.0	27.0			16
2	2022-10-21 12:21:26	53.38	0.00	100.00	100	107.23	107.23	1.0	27.0	27.0			16




12



Press 'Up' and 'Down' to choose the setting item No., press 'Enter' to enter into the detailed setting parameter, when finish press 'Enter' again. The following setting items need to be set follow the recommended value:

Item No.	Setting Value
Program 02	Set to N*25A, N=battery amount
Program 05	Set to USE
Program 12	Set to 48V
Program 13	Set to 51V
Program 26	Set to 53.2V
Program 29	Set to 47.5V




**Note:**

1. PIP Inverters can only be waked up via battery, if the battery is turned off due to over-discharge, over temp. or other reasons, in order to wake up the inverter you need turn on the battery manually.
2. As there is no communication between inverter and battery, for a better using experience, it's also acceptable to introduce monitoring device to visually display the real-time information from battery management system via the communication channel, such as Inverter Control Center(ICC) from centurionsolar. Same as the inverter compatibility condition, such a monitoring system needs get authorization from Pylontech in advance for the compatibility before using with the products from Pylontech mentioned above, otherwise the products from Pylontech will be exclusive of warranty.

# THE HISTORY OF THE UNITED STATES

OF THE



OF THE

HM

### 9.3. Settings for no communication situation

Without communication protocol, inverter cannot communicate with our battery. You need to make some setting on your inverter, for example, select the user-defined mode and set the corresponding voltage level (according to the inverter user manual), so that they can work together without communication.

Here are some commonly used battery parameters that need to be set, for reference. If need more advices about battery parameters settings, please contact the manufacturer.

	Over Voltage <u>Disconnect Voltage</u>	57.6V <del>NO</del>
	<u>Charging Limit Voltage</u>	58.4V <del>MAX</del> DEAD
	<u>Equalizing Charging Voltage</u>	56V
27 29	<u>Float Charging Voltage</u>	54V <del>54</del>
	<u>Low Voltage Warning Voltage</u>	(45V)
29 13	<u>Cut-off Discharge Voltage</u>	43.2V
	<u>Discharge Limit Voltage</u>	40V EMPTY

Pylontech:

Item No.	Setting Value	
Program 02	Set to N*25A, N=battery amount	✓ CURR
Program 05	Set to USE	✓ TYPE
Program 12	Set to 48V	GRID
Program 13	Set to 51V	DISCHG ✓
Program 26	Set to 53.2V	BULK CHG
Program 29	Set to 47.5V	FLOAT CHG ✓

THE UNIVERSITY OF CHICAGO  
DEPARTMENT OF CHEMISTRY  
5800 S. UNIVERSITY AVENUE  
CHICAGO, ILLINOIS 60637

RESEARCH ASSISTANT  
MRS. J. H. HARRIS  
5800 S. UNIVERSITY AVENUE  
CHICAGO, ILLINOIS 60637

RESEARCH ASSISTANT  
MRS. J. H. HARRIS  
5800 S. UNIVERSITY AVENUE  
CHICAGO, ILLINOIS 60637

RESEARCH ASSISTANT  
MRS. J. H. HARRIS  
5800 S. UNIVERSITY AVENUE  
CHICAGO, ILLINOIS 60637

RESEARCH ASSISTANT  
MRS. J. H. HARRIS  
5800 S. UNIVERSITY AVENUE  
CHICAGO, ILLINOIS 60637

## LCD Setting

After pressing and holding ENTER button for 3 seconds, the unit will enter setting mode. Press "UP" or "DOWN" button to select setting programs. And then, press "ENTER" button to confirm the selection or ESC button to exit.

### Setting Programs:

Program	Description	Selectable option
00	Exit setting mode	Escape 00 ESC
01	Output source priority: To configure load power source priority	Solar first 01 SOL
		Utility first (default) 01 UTI
		SBU priority 01 SBU
		<p>Solar energy provides power to the loads as first priority. If solar energy is not sufficient to power all connected loads, battery energy will supply power the loads at the same time. Utility provides power to the loads only when any one condition happens: - Solar energy is not available - Battery voltage drops to either low-level warning voltage or the setting point in program 12.</p> <p>Utility will provide power to the loads as first priority. Solar and battery energy will provide power to the loads only when utility power is not available.</p> <p>Solar energy provides power to the loads as first priority. If solar energy is not sufficient to power all connected loads, battery energy will supply power to the loads at the same time. Utility provides power to the loads only when battery voltage drops to either low-level warning voltage or the setting point in program 12.</p>

02	Maximum charging current: To configure total charging current for solar and utility chargers. (Max. charging current = utility charging current + solar charging current)	10A 02 10 <sup>A</sup>	20A 02 20 <sup>A</sup>
		30A 02 30 <sup>A</sup>	40A 02 40 <sup>A</sup>
		50A 02 50 <sup>A</sup>	60A (default) 02 60 <sup>A</sup>
		70A 02 70 <sup>A</sup>	80A 02 80 <sup>A</sup>
03	AC input voltage range	Appliances (default) 03 APL	If selected, acceptable AC input voltage range will be within 90-280VAC.
		UPS 03 UPS	If selected, acceptable AC input voltage range will be within 170-280VAC.
04	Power saving mode enable/disable	Saving mode disable (default) 04 SDS	If disabled, no matter connected load is low or high, the on/off status of inverter output will not be effected.
		Saving mode enable 04 SEN	If enabled, the output of inverter will be off when connected load is pretty low or not detected.
05	Battery type	AGM (default) 05 AGM	Flooded 05 FLD
		User-Defined 05 USE	If "User-Defined" is selected, battery charge voltage and low DC cut-off voltage can be set up in program 26, 27 and 29.
06	Auto restart when overload occurs	Restart disable (default) 06 LTD	Restart enable 06 LFE
07	Auto restart when over temperature occurs	Restart disable (default) 07 LTD	Restart enable 07 LFE
08	Output voltage	220V 08 220 <sup>v</sup>	230V (default) 08 230 <sup>v</sup>
		240V 08 240 <sup>v</sup>	

09	Output frequency	50Hz (default) 09 50 Hz	60Hz 09 60 Hz
11	Maximum utility charging current	2A 11 2A	10A 11 10A
		20A 11 20A	30A (default) 11 30A
		40A 11 40A	50A 11 50A
		60A 11 60A	70A 11 70A
		80A 11 80A	
12	Setting voltage point back to utility source when selecting "SBU priority" or "Solar first" in program 01.	Available options in 48V models:	
		44V 12 BATT 44v	45V 12 BATT 45v
		46V (default) ? 12 BATT 46v	47V 12 BATT 47v
		48V 12 BATT 48v	49V 12 BATT 49v
		50V 12 BATT 50v	51V 12 BATT 51v
		52V 12 BATT 52v	53V 12 BATT 53v
		54V 12 BATT 54v	55V 12 BATT 55v
		56V 12 BATT 56v	57V 12 BATT 57v

		Available options in 48V models:	
		Battery fully charged	48V
		13 <sup>BATT</sup> FUL	13 <sup>BATT</sup> 48 <sup>v</sup>
		49V	50V
		13 <sup>BATT</sup> 49 <sup>v</sup>	13 <sup>BATT</sup> 50 <sup>v</sup>
		51V	52V
		13 <sup>BATT</sup> 51 <sup>v</sup>	13 <sup>BATT</sup> 52 <sup>v</sup>
		53V	54V (default)
		13 <sup>BATT</sup> 53 <sup>v</sup>	13 <sup>BATT</sup> 54 <sup>v</sup>
		55V	56V
		13 <sup>BATT</sup> 55 <sup>v</sup>	13 <sup>BATT</sup> 56 <sup>v</sup>
		57V	58V
		13 <sup>BATT</sup> 57 <sup>v</sup>	13 <sup>BATT</sup> 58 <sup>v</sup>
		59V	60V
		13 <sup>BATT</sup> 59 <sup>v</sup>	13 <sup>BATT</sup> 60 <sup>v</sup>
		61V	62V
		13 <sup>BATT</sup> 61 <sup>v</sup>	13 <sup>BATT</sup> 62 <sup>v</sup>
		63V	64V
		13 <sup>BATT</sup> 63 <sup>v</sup>	13 <sup>BATT</sup> 64 <sup>v</sup>

13

Setting voltage point back to battery mode when selecting "SBU priority" or "Solar first" in program 01.

16	Charger source priority: To configure charger source priority	If this inverter/charger is working in Line, Standby or Fault mode, charger source can be programmed as below:	
		Solar first 16 C50	Solar energy will charge battery as first priority. Utility will charge battery only when solar energy is not available.
		Utility first 16 CUE	Utility will charge battery as first priority. Solar energy will charge battery only when utility power is not available.
		Solar and Utility (default) 16 SNU	Solar energy and utility will charge battery at the same time.
		Only Solar 16 O50	Solar energy will be the only charger source no matter utility is available or not.
		If this inverter/charger is working in Battery mode or Power saving mode, only solar energy can charge battery. Solar energy will charge battery if it's available and sufficient.	
18	Alarm control	Alarm on (default) 18 60N	Alarm off 18 60F
19	Auto return to default display screen	Return to default display screen (default) 19 ESP	If selected, no matter how users switch display screen, it will automatically return to default display screen (Input voltage /output voltage) after no button is pressed for 1 minute.
		Stay at latest screen 19 FEP	If selected, the display screen will stay at latest screen user finally switches.
20	Backlight control	Backlight on (default) 20 LON	Backlight off 20 LOF
22	Beeps while primary source is interrupted	Alarm on (default) 22 RON	Alarm off 22 ROF
23	Overload bypass: When enabled, the unit will transfer to line mode if overload occurs in battery mode.	Bypass disable (default) 23 BYD	Bypass enable 23 BYE
25	Record Fault code	Record enable 25 FEN	Record disable (default) 25 FdS

1. The first part of the document is a list of names.

2. The second part of the document is a list of names.

3. The third part of the document is a list of names.

4. The fourth part of the document is a list of names.

5. The fifth part of the document is a list of names.

6. The sixth part of the document is a list of names.

7. The seventh part of the document is a list of names.

8. The eighth part of the document is a list of names.

9. The ninth part of the document is a list of names.

10. The tenth part of the document is a list of names.

11. The eleventh part of the document is a list of names.

12. The twelfth part of the document is a list of names.

13. The thirteenth part of the document is a list of names.

14. The fourteenth part of the document is a list of names.

15. The fifteenth part of the document is a list of names.

16. The sixteenth part of the document is a list of names.

17. The seventeenth part of the document is a list of names.

18. The eighteenth part of the document is a list of names.

19. The nineteenth part of the document is a list of names.

20. The twentieth part of the document is a list of names.

21. The twenty-first part of the document is a list of names.

22. The twenty-second part of the document is a list of names.

23. The twenty-third part of the document is a list of names.

24. The twenty-fourth part of the document is a list of names.

25. The twenty-fifth part of the document is a list of names.

26. The twenty-sixth part of the document is a list of names.

27. The twenty-seventh part of the document is a list of names.

28. The twenty-eighth part of the document is a list of names.

29. The twenty-ninth part of the document is a list of names.

30. The thirtieth part of the document is a list of names.

31. The thirty-first part of the document is a list of names.

32. The thirty-second part of the document is a list of names.

33. The thirty-third part of the document is a list of names.

34. The thirty-fourth part of the document is a list of names.

35. The thirty-fifth part of the document is a list of names.



















36. The thirty-sixth part of the document is a list of names.

37. The thirty-seventh part of the document is a list of names.

38. The thirty-eighth part of the document is a list of names.

39. The thirty-ninth part of the document is a list of names.

40. The fortieth part of the document is a list of names.

26	Bulk charging voltage (C.V voltage)	default setting: 56.4V ?  54V (56V)					
If self-defined is selected in program 5, this program can be set up. Setting range is from 48.0V to 64.0V. Increment of each click is 0.1V.							
27	Floating charging voltage	default setting: 54.0V 					
If self-defined is selected in program 5, this program can be set up. Setting range is from 48.0V to 64.0V. Increment of each click is 0.1V.							
29	Low DC cut-off voltage	default setting: 42.0V 					
If self-defined is selected in program 5, this program can be set up. Setting range is from 40.0V to 54.0V. Increment of each click is 0.1V. Low DC cut-off voltage will be fixed to setting value no matter what percentage of load is connected.							
31	Solar power balance: When enabled, solar input power will be automatically adjusted according to connected load power.	<table border="1"> <tr> <td data-bbox="708 1115 999 1290">           Solar power balance enable (Default):   </td> <td data-bbox="999 1115 1383 1290">           If selected, solar input power will be automatically adjusted according to the following formula:            Max. input solar power = Max. battery charging power + Connected load power.         </td> </tr> <tr> <td data-bbox="708 1290 999 1547">           Solar power balance disable:   </td> <td data-bbox="999 1290 1383 1547">           If selected, the solar input power will be the same to max. battery charging power no matter how much loads are connected. The max. battery charging power will be based on the setting current in program 02.            (Max. solar power = Max. battery charging power)         </td> </tr> </table>	Solar power balance enable (Default): 	If selected, solar input power will be automatically adjusted according to the following formula: Max. input solar power = Max. battery charging power + Connected load power.	Solar power balance disable: 	If selected, the solar input power will be the same to max. battery charging power no matter how much loads are connected. The max. battery charging power will be based on the setting current in program 02. (Max. solar power = Max. battery charging power)	
Solar power balance enable (Default): 	If selected, solar input power will be automatically adjusted according to the following formula: Max. input solar power = Max. battery charging power + Connected load power.						
Solar power balance disable: 	If selected, the solar input power will be the same to max. battery charging power no matter how much loads are connected. The max. battery charging power will be based on the setting current in program 02. (Max. solar power = Max. battery charging power)						
32	Bulk charging time (C.V stage)	<table border="1"> <tr> <td data-bbox="708 1547 999 1666">           Automatically (Default):   </td> <td data-bbox="999 1547 1383 1666">           If selected, inverter will judge this charging time automatically.         </td> </tr> <tr> <td data-bbox="708 1666 999 1778">           5 min   </td> <td data-bbox="999 1666 1383 1921" rowspan="2">           The setting range is from 5 min to 900 min. Increment of each click is 5 min.         </td> </tr> <tr> <td data-bbox="708 1778 999 1921">           900 min   </td> </tr> </table>	Automatically (Default): 	If selected, inverter will judge this charging time automatically.	5 min 	The setting range is from 5 min to 900 min. Increment of each click is 5 min.	900 min 
Automatically (Default): 	If selected, inverter will judge this charging time automatically.						
5 min 	The setting range is from 5 min to 900 min. Increment of each click is 5 min.						
900 min 							
If "USE" is selected in program 05, this program can be set up.							

33	Battery equalization	Battery equalization 33 EEN	Battery equalization disable (default) 33 EdS
		If "Flooded" or "User-Defined" is selected in program 05, this program can be set up.	
34	Battery equalization voltage	Default setting is 58.4V. Setting range is from 48V ~ 64V. Increment of each click is 0.1V. EV 34 BATT 64.0v	
35	Battery equalized time	60min (default) 35 60	Setting range is from 5min to 900min. Increment of each click is 5min.
36	Battery equalized timeout	120min (default) 36 120	Setting range is from 5min to 900 min. Increment of each click is 5 min.
37	Equalization interval	30days (default) 37 30d	Setting range is from 0 to 90 days. Increment of each click is 1 day
39	Equalization activated immediately	Enable 39 AEN	Disable (default) 39 AdS
		If equalization function is enabled in program 33, this program can be set up. If "Enable" is selected in this program, it's to activate battery equalization immediately and LCD main page will shows "E9". If "Disable" is selected, it will cancel equalization function until next activated equalization time arrives based on program 37 setting. At this time, "E9" will not be shown in LCD main page.	


### Pylontech Lithium Battery Support

Date: 20 Feb 2019  
 By: MPP Solar  
 Comment:  
 Comments are off



February 20th, 2019

We are pleased to announce that, starting January 2019, all our Hybrid and Off-Grid Solar Inverters are now officially compatible for use with **Pylontech US2000B Plus/3000 Lithium batteries**, in 3 ways.




#### MPI Hybrid Application with BMS

- MPI Hybrid models starting January 2019 will now be able to work with Pylontech Lithium batteries through the use of optional RS485 Modbus Card (sold separately). Simply install RS485 card into Hybrid inverter's intelligent slot, then connect the card to Pylontech's BMS port and it is automatic compatibility. **Please note MPI Hybrid units produced prior to January 2019 will NOT be able to support Pylontech batteries.**

#### 5048GK / 5048MK with Pylontech BMS

- Starting January 2019, all units 5048GK / 5048MK are now ready to communicate directly with Pylontech BMS battery system through the use of a direct data communication from inverter's BMS port to the battery. A special data cable sold separately will be required for this purpose. **Please note 5048GK / 5048MK produced prior to January 2019 will NOT be able to support Pylontech BMS communication.**




Faint, illegible text or markings in the upper center of the page, possibly a title or header.


Large block of extremely faint, illegible text or a diagram occupying the middle section of the page.

MPP Solar Store is now ready. visit [visit](#)

x



### PIP Off-Grid Series with Pylontech without BMS



#### Application without BMS

- For application without BMS, our Off-Grid inverter family (PIP-HS/MS, PIP-HSE/MSE/MSXE, PIP-GE, PIP-MSD/MST, and older versions of PIP-C programmed to match setting with Pylontech batteries. For normal daily use it is not mandatory to use BMS with Pylontech batteries provided the done correctly. It should be noted that without BMS, the inverter's display of battery SOC may not be very accurate. Please refer to [Pylontech cc](#) on how to program your inverter to use with Pylontech batteries without BMS support.

Should you have any questions, please feel free to contact our [Sales team](#) for further information. Thank you for your attention.





# 51.2V LiFePO4 Battery

LFP48100P~48230P



## Completed

If the item you received is defective or not as described, you can open a dispute within 15 days of receipt.

Add to cart

Track order

Download invoice



Kalman Push

+1 4808239691

Phoenix, Arizona, United States, 85041




Order ID: 8183508635911020 [Copy](#)

Order placed on: Jan 3, 2024

Payment method: Credit/Debit card

[Blmpow Official Store](#) >



LiFePO4 48V 200AH Battery Pack 51.2V 10KW Lithium Solar Battery 6000 Cycle With 16S ...

48V 100AH 5KW, CHINA

\$1,179.72 x1

Free returns

Add to cart

Add additional review

Returns/refunds

Subtotal	\$1,179.72
Shipping	Free shipping
Coins	-\$0.87
AliExpress Coupon	-\$0.10
Tax	\$101.38
<b>Total</b>	<b>\$1,280.13</b>

21 1/2  
100 1/2



100 1/2

100 1/2

100 1/2

100 1/2

100 1/2

Home > Orders > Order details

Account

Overview

Orders

Payment

Refund and return

Feedback

Settings

Shipping address

Message center

Invite friends

Help center

Manage reports

Suggestion

DS Center

AliExpress Mobile App

Search Anywhere, Anytime!



Scan or click to download

Completed

If the item you received is defective or not as described, you can open a dispute within 15 days of receipt.

Add to cart

Track order

Download invoice

Kalman Push  
+1 4808239691  
Phoenix, Arizona, United States, 85041

Order ID: 8183508635911020 Copy  
Order placed on: Jan 3, 2024  
Payment method: Credit/Debit card

Blmpow Official Store >

LiFePO4 48V 200AH Battery Pack 51.2V 10KW Lithium Solar Battery 6000 Cycle Wit...  
48V 100AH 5KW, CHINA  
\$ 1,179.72 x1  
Free returns

Add to cart

Add additional review

Returns/refunds

Subtotal	\$1,179.72
Shipping	Free shipping
Coins	-\$0.87
AliExpress Coupon	-\$0.10
Tax	\$101.38
<b>Total</b>	<b>\$ 1,280.13</b>

More to love

2024 New ECG Sm...  
3 sold  
**\$60.72**  
Extra 2% off with co...  
Free shipping

48V 100Ah LiFePO...  
57 sold  
**\$1,001.71**  
Extra 3% off with co...  
Free shipping

NORTH EDGE Bod...  
**\$48.86**  
Extra 5% off with co...  
Free shipping

360pcs LED 660n...  
6 sold  
**\$109.45**  
Free shipping

Adult Child Elder...  
1 sold  
**\$444**

Help

Help Center, Disputes & Reports, Buyer Protection, Report IPR infringement, Regulated Information, Integrity Compliance

AliExpress Multi-Language Sites



Need Help?



11

The first part of the document discusses the importance of maintaining accurate records of all transactions. It emphasizes that proper record-keeping is essential for ensuring the integrity and reliability of financial data. This section also outlines the various methods and tools used to collect and analyze financial information, highlighting the need for consistency and transparency in the reporting process.

The second part of the document focuses on the specific procedures and protocols that must be followed to ensure the accuracy and completeness of the data. It details the steps involved in data collection, from identifying the relevant sources to the final verification and approval of the records. This section also addresses the challenges and potential pitfalls associated with data collection and provides practical advice on how to overcome them.

The third part of the document discusses the importance of data security and privacy. It outlines the measures that should be taken to protect sensitive information from unauthorized access, loss, or disclosure. This section also addresses the legal and ethical considerations surrounding data collection and storage, ensuring that all activities are conducted in compliance with applicable laws and regulations.

The fourth part of the document provides a summary of the key findings and conclusions of the study. It highlights the main insights gained from the data and discusses the implications of these findings for future research and practice. This section also includes a list of references and a list of figures and tables, providing a comprehensive overview of the document's content.



Kalman Push  
+1 4808239691  
Phoenix, Arizona, United States, 85041  
Order ID: 8183508635911020Copy  
Order placed on: Jan 3, 2024  
Payment method: Credit/Debit card  
**Blmpow Official Store**

LiFePO4 48V 200AH Battery Pack 51.2V 10KW Lithium Solar Battery 6000 Cycle With 16S 200A  
BMS Max 32 parallel For Inverter NO TAX

48V 100AH 5KW, CHINA

**\$1,179.72**

x1

[Free returns](#)

[Add to cart](#)[Add additional review](#)[Returns/refunds](#)

Subtotal \$1,179.72

Shipping Free shipping

Coins **-\$0.87**

AliExpress Coupon **-\$0.10**

Tax \$101.38

**Total**

**\$1,280.13**



# Invoice

**Supplier name** Blmpow Official Store **Customer Name** Kalman Push  
**Marketplace Facilitator** Alibaba.com Singapore E-Commerce Private Limited **Delivery Address** 7406 S 40th Ave Phoenix Arizona

				Invoice Date	Invoice No.
				2024-01-03 -0700	B10MZA20240104030051
Transaction	Quantity	Price (USD)	Sales Tax Rate	Sales Tax Amount (USD)	Total inclusive of Sales Tax (USD)
LiFePO4 48V 200AH Battery Pack 51.2V 10KW Lithium Solar Battery 6000 Cycle With 16S 200A BMS Max 32 parallel For Inverter NO TAX	1	1178.85	8.600%	101.38	1280.23
<b>Total amount in USD</b>				101.38	1280.23

\*As required by the relevant State Sales Tax Laws, the marketplace facilitator is required to collect Sales Tax and remit to the relevant tax authorities.

