



How to set up Fldpipe to work under other users:


1. Run regedit (under Windows 2000/NT regedit32)
2. Go to **HKEY\_LOCAL\_MACHINE → SOFTWARE → FineLine** entry, then right click with the mouse.
3. Select the “Permissions...” menu




4. Then click to “Advanced”



5. Uncheck the “Inherit from...” checkbox, then click to copy, Check “Replace permissions...”



6. Double click on the user/group name, and then give full control to it.



7. Click on "OK", to Apply.

8. Make sure that the user has write (rwm) permissions to "C:\Program Files\FineLine\PC DataPipe\Temp"

If not present, as admin right click on the folder, then security tab and do the same from step 4.