


Print the settings to compare (OKIDATA320):



- 1 Make sure paper is loaded in the printer.
- 2 Enter the Menu Mode (**SHIFT + SEL**).
- 3 Press PRINT (**P** key).